



Fans and Pumps Tips

- D Clean or replace clogged air filters.
- Deplace leaky pump seals.
- > Shut down fans and pumps when they aren't required.





